External hard disk

SPD5220
SPD5230
SPD5240
SPD5250

EN	User manual	3
F	Manuel d'instructions	9
D	Benutzerhandbuch	15
NL	Gebruikershandleiding	21
ES	Manual del usuario	27
I	Manuale utente	33
PT	Manuel do utilizador	39
TR	Kurulum Kılavuzu	45

PHILIPS

Contents

EN

4 What's in the box?

5 How to connect this external hard disk to your computer?

5 How to safely disconnect?

6 How to use the One-Click Back-Up button?

6 How to install for Mac, Windows 98 SE or Windows ME?

7 Warranty, Environment and Safety

8 Specifications

Important note

To start using the One-Click Back-Up button, first activate the Carry it Easy software (once only) by clicking on the CarryitEasy.exe file located on your hard disk. For instructions and more information, see page 6.

When the computer does not recognize the hard disk (some computers provide insufficient bus power), we advise you to use the Y-cable supplied together with this product. For instructions and more information, see page 5.

What's in the box?

A : External hard disk

B : Y-cable

C : Quick Start Guide

How to connect this external hard disk on your system?

Plug the wrap around USB cable into an empty USB port of your computer.
A drive icon, Philips External Hard Disk, appears in Windows Explorer. (The computer sometimes needs to be restarted, before you can use the new hardware).

When the computer does not recognize the hard disk (some computers provide insufficient bus power), we advise you to use the Y-cable supplied together with this product. Connect the Y-cable to the USB cable of the hard disk and plug in the 2 connectors in the free USB ports of your computer. The black connector is for data transfer and power, the gray connector is for additional power only.

How to safely disconnect?

1 Double-click the **Safely Remove Hardware** icon in the task bar in the lower right part of the screen.

2 In the window that appears, select the name of the device that is to be removed, then click the **Stop** button.

3 When the **Stop a hardware device** screen appears, make sure the correct information is displayed, and then click the **OK** button.

4 When the message **Safe to remove hardware** appears, remove the drive from the computer's USB port.